

## 864 0250 QuickControl 4.0 IP

### Common description

The system QuickControl 4.0 IP is a web-based button controller and needs no software for configuring without a standard web browser.

**The system QuickControl 4.0 IP is software independant**

The user interface for configuration is part of QuickControl 4.0 IP and can be reached by web from every computer, tablet or smartphone.

See installation drawing no. 1 and the information on page 8 of the user manual. The user interface is nearly self explanatory, also everything is explained in the user manual.

### LAN

The system QuickControl 4.0 IP can be integrated in every LAN. In a professional usage you will have no trouble with the LAN, because of the low data rate you need for the control codes.

The professional installation in the LAN must be done in accordance with the IT-management. The factory default IP-address must be changed to the needed address for the network. You will find the description in the web user interface and in the manual on page 8-9.

Installationszeichnung1